



NO.	PARTS NAME	Q'TY	NO.	PARTS NAME	Q'TY
1-A	console upper cover	1	29	spring washer $\phi 8.1-\phi 13.5 \times 1.5$	2
1-B	PCB board	1	30	bolt M8*12	2
1-C	display upper cover	1	31	controller board	1
1-D	display down cover	1	32	motor belt	1
1-E	fixed piece	1	33	cable lock	1
1-F	console down cover	1	34	switch	1
1-G	button board	1	35	fuse	1
1-H	button sticker	1	36	front roller	1
1-I	rotary sticker	2	37	bolt M8*55	3
1-J	speaker	2	38	lower connect cable	1
2	screw $\phi 3 \times 7$	6	39	running board	1
3	screw $\phi 4.2 \times 13$	16	40	bolt M6*35	8
4	safety key	1	41	rear roller	1
5	hand pulse	2	42	end cap	1
6	handle foam	2	43	side rail	2
7	plastic tube	2	44	running belt	1
8	tube cover	2	45	motor upper cover	1
9	flat washer $\phi 9-\phi 16 \times 1.6$	22	46	bolt M5*15	4
10	bolt M8*15	10	47	side rail fixer	6
11	handle frame	1	48	upper connect cable	1
12	flat washer $\phi 5.5-\phi 10 \times 1.0$	4	49	bolt M4.2*30	8
13	upright post	2	50	bolt M8*45	1
14	screw $\phi 4 \times 65$	2	51	silicone oil	1
15	nut M8	10	52	power cable	1
16	incline frame	1	53	Allen key	1
17	bolt M10*50	4	54	motor base	1
18	nut M10	4	55	bolt M4*16	4
19	flat washer $\phi 11-\phi 21 \times 1.5$	4	56	incline motor	1
20	moving wheel	2	57	bolt M10*45	1
21	foot pad	2	58	bolt M8*45	2
22	gas spring	1	59	cushion	8
23	motor down cover	1	60	base frame	1
24	bolt M8*30	1	61	bolt M8*40	4
25	bolt ST4.2*12	16	62	cushion upper cover	4
26	main frame	1	63	cushion rubber sleeve	4
27	motor	1	64	spring	4
28	bolt M8*20	4	65	cushion lower cover	4